

X5105_App_V3.00_build007 Firmware Description

1. After the firmware is updated, please hold press and hold MENU + power button (power on) --- -- to initialize ----- select YES, wait about 5 seconds;
2. Press any key (except the Power button) to enter the boot process;
3. After powering on, perform another power on/off action.

At this point, the initialization is complete.

Calibration of the S table:

1. After unplugging the antenna, into the S meter calibration item in the system menu;
2. Rotate the main knob until the calibration table shows the minimum S0;
3. Save and exit.

Firmware fix:

Corrected the CW's bug (lose the "-" or "-") .

2, fixed the known bug

3. Added the PTT or hand mic PTT button that comes with the host as the function of the hand button to launch CW.

Instructions for using MIC and LINE IN:

Please note that the two cannot be used at the same time. When using the MIC, set LINE IN to OFF.